

MEASURING GUIDE

Accurate Measurements Are Important

To insure prompt and efficient processing of your order, accurate centerline measurements must be provided.

General Information

- Centerline measurements of the finished shower area are required
- All tile, sills and or thresholds must be installed before measuring.
- Out of plumb and level conditions must be noted.
- Specify hinge location of swing doors
- Specify locations of showerheads and body sprays
- Tools required: tape measure and levels

**** The measuring templates provided are for dimensional conditions only. Dealer purchase orders must be included when ordering.**